

# Self-Bearing Linear-Rotary Actuators with Wireless Power Transfer for High-Purity and Precision Applications

Spasoje Mirić, Rosario V. Giuffrida, Prasad Jayathurathnage, Johann W. Kolar



Swiss Federal Institute of Technology (ETH) Zurich Power Electronic Systems Laboratory www.pes.ee.ethz.ch

May 15, 2023, San Francisco







# Self-Bearing Linear-Rotary Actuators with Wireless Power Transfer for High-Purity and Precision Applications

#### Spasoje Mirić et al.



University of Innsbruck, Institute for Mechatronics
Innsbruck Drives and Energy Systems Laboratory (iDES)
<a href="https://www.uibk.ac.at/mechatronik/ides/">www.uibk.ac.at/mechatronik/ides/</a>

May 15, 2023, San Francisco







## **Outline**

## Part 1

- **►** Introduction
- LiRA Examples / Applications
- Linear Actuator with Integrated MBs
- Position Sensors
- ► Dynamic Modeling, Controller Design
- Generalized Complex Space Vector
- Double Stator LiRA
- Outlook

**ETH** zürich

## Part 2

- **►** Introduction
- ► Application: Blood Pumps
- Sensors for SB-LiRAs
- ► Design Example: the ShuttlePump
- Outlook

## Part 3

- Introduction
- WPT to Linear Actuators
- Orthogonal and Parallel Field Concept
- Supplying Multiple Receivers Voltage & Current Impressed WPT
- **▶** Outlook





San Francisco, CA May 15-18





## **Outline**

## Part 1

- **►** Introduction
- LiRA Examples / Applications
- ► Linear Actuator with Integrated MBs
- **▶** Position Sensors
- Dynamic Modeling, Controller Design
- Generalized Complex Space Vector
- Double Stator LiRA
- Outlook

## Part 2

- **▶** Introduction
- ► Application: Blood Pumps
- Sensors for SB-LiRAs
- **▶** Design Example: the ShuttlePump
- Outlook

## Part 3

- **►** Introduction
- WPT to Linear Actuators
- Orthogonal and Parallel Field Concept
- Supplying Multiple Receivers Voltage & Current Impressed WPT
- Outlook









Introduction

Linear Rotary Actuators (LiRAs) ———— Applications LiRA Examples








## universität innsbruck

## **Linear-Rotary Actuator (LiRA)**

- LiRA is conceived by coupling Linear and Rotary actuators (machines)
- Types of coupling: Mechanical, Magnetic, Double Stator



- Intended use determines the type of the LiRA, i.e., the type of coupling Parallel mechanical coupling → simple to realize, but low dynamics & moving cables








## **LiRA Application Examples**

Source SMAC

A wide spectrum of application areas: servo, tools, industrial automation, robot end-effector, blood pumps




■ Servo




**■** Lathe




**■ Industry Assembly Lines** 




■ Pick & Place Robot in **Electronics/Semiconductor Industry** 



**■** Handling/Dosing in Pharmaceutical/Chemical Industry



**■** ShuttlePump





universität innsbruck







- Series mechanical coupling > three-phase slotless PM rotary actuator (top) & linear actuator (bottom)
- Pick&Place LiRA enables rotational and translational motion for small component placement



Parameter	Value		
$z_{stroke}$	±5 mm		
$\phi_{stroke}$	±180° degrees		
$z_{err}$	5 μm		
$\phi_{err}$	3 mrad		
$\alpha_z$	$150 \text{ m s}^{-2}$		
$\alpha_{\phi}$	7700 rad $s^{-2}$		
$v_{max}$	$3 \text{ m s}^{-1}$		
$\omega_{max}$	$135 \text{ rad s}^{-1}$		
$d_z$	0.22		
$d_{\phi}$	0.39		
$d_{\phi} \ L_{z\phi}$	105 mm		
$r_{o,max}$	30 mm		
$r_{i,min}$	18 mm		

High accelerations required

Rather a low max. speed

**■** Specifications

- Component placement throughput → high dynamics/accelerations
  Actuator operation → low speeds due to limited stroke (acceleration/deceleration)










- Series mechanical coupling → three-phase rotary actuator & three-phase linear actuator
- Pick&Place LiRA enables rotational and translational motion for small component placement





- Cogging force due to end effects → minimization by optimizing stator core geometry / placement Passive gravity compensation → force profile optimized in 3D-FEM by varying geometry

[ref] Meessen, K. J., J. J. H. Paulides, and E. A. Lomonova, "Analysis and design considerations of a 2-DoF rotary-linear actuator," 2011 IEEE International Electric Machines & Drives Conference (IEMDC), IEEE, 2011.









- Three-phase rotary actuator & slotless linear actuator winding in the air gap
- Pick&Place LiRA enables rotational and translational motion for small component placement











- Single set of mover permanent magnets → special arrangement to interact with rotary and linear windings Large air gap → low cogging force; but low machine constant


[ref] Meessen, Koen Joseph. "Electric Eng., Eindhoven Univ. Technol., the Netherlands (2012).








- Moving coil rotary actuator & moving coil linear actuator
- Pick&Place LiRA enables rotational and translational motion for small component placement





- Limited rotary stroke due to permanent magnet field arrangement → parts with no radial field Moving coils → moving cables limit lifetime

[ref] Teo, Tat Joo, et al. "Principle and modeling of a novel moving coil linear-rotary electromagnetic actuator." IEEE Transactions on Industrial Electronics 63.11 (2016): 6930-6940. https://www.youtube.com/watch?v=ApWlagkbrE0









San Francisco, CA May 15-18




- Concentrated coils in linear and rotary direction → 'checkerboard actuator'
- Checkerboard direct drive LiRA enables rotational and translational motion









- LiRA with magnetic coupling → highest compactness, increased number of phases, increased control effort Ideally no end windings → end winding for the linear direction is an active part of the winding for rotary direction


[ref] Jin, Ping, et al. "3-D analytical linear force and rotary torque analysis of linear and rotary permanent magnet actuator." IEEE transactions on magnetics 49.7 (2013): 3989-3992.







- Double stator LiRA → 'magnetically insulated' linear and rotary parts
- Three-phase linear and rotary machines, controlled independently





- Large force (650 N) / torque (10 Nm), dynamics limited due to the large moving mass of the mover Challenging design → cooling of the inner stator, mover back iron with two sets of PMs


[ref] Xu, Lei, et al. "Design and analysis of a double-stator linear-rotary permanent-magnet motor." IEEE Transactions on Applied Superconductivity 26.4 (2016): 1-4.








- Helical winding (inner and outer)  $\rightarrow$  independent thrust force and torque generation/control
- Slotless LiRA proposed usage for surgery robots in medicine









- Limited force (5 N)/torque (0.1 Nm) due to slotless winding, helical winding complicated to realize Mover PMs the same as for the checkerboard actuator

[ref] Tanaka, Shodai, Tomoyuki Shimono, and Yasutaka Fujimoto. "Optimal design of length factor for cross-coupled 2-DOF motor with Halbach magnet array." 2015 IEEE International Conference on Mechatronics



universität innsbruck





**Need for Improvements** 


Application Requirements Conventional Bearings Bearingless / Self-bearing





## **High Precision Requirement**

- High dynamics robot  $\rightarrow$  reaches accelerations of 150  $^{\rm m}/_{\rm s^2}$  and speeds of 5  $^{\rm m}/_{\rm s}$  Horizontal workspace of 300 mm  $\times$  300 mm; repeatability < 10  $\mu m$




- Thermal expansions in parallel kinematics deteriorate precision → LiRA with radial position control Handling smaller components/dies → mover tilting necessary Mechanical/air bearings used in conventional LiRAs can not control radial position nor tilting





## **High Purity Requirement**

- Applications requiring high purity → clean rooms, bioprocessing, pharmaceutical Mechanical bearings → limited lifetime / limited purity levels / often disassembling for cleaning







**■** Disassembling for regular high-pressure washdowns

- Air bearings → require air supply / prohibited operation in low-pressure environments
- High precision & high purity requirements limit usage of LiRAs with conventional bearings

[ref] Paulides, Johannes JH, Jeroen LG Janssen, and Elena A. Lomonova. "Bearing lifetime of linear PM machines." 2009 IEEE Energy Conversion Congress and Exposition. IEEE, 2009.










## **Magnetic Bearings (MBs)**

- Magnetic bearings → generate radial forces to keep the rotor/mover centered
- Closed loop position controller → sensor, microcontroller, power converter, MB windings





- Characteristics → free of contact, no contaminating wear, bearing stiffness control, low maintenance
- Applications → vacuum and clean room system, high-speed pumps, high-purity pumps, flywheels


[ref] Maslen, Eric H., and Gerhard Schweitzer, eds. Magnetic bearings: theory, design, and application to rotating machinery. Berlin, Heidelberg: Springer-Verlag Berlin Heidelberg, 2009.








## **Standalone MBs and Self-bearing/Bearingless Machines**


- Self-bearing/Bearingless → integrate MBs into the existing machine structure
- Achieve self-bearing function  $\rightarrow$  superimpose the main field (torque, p poles) with the  $p \pm 2$  type


























P-2

P+2

- Tilting control of the long shaft  $\rightarrow$  either  $(F_b) \& (T, F_b)$  or  $(T, F_b) \& (T, F_b)$   $p \pm 2$  type is achieved by winding scheme or current distribution in the existing main windings

[ref] Maslen, Eric H., and Gerhard Schweitzer, eds. Magnetic bearings: theory, design, and application to rotating machinery. Berlin, Heidelberg: Springer-Verlag Berlin Heidelberg, 2009.









### **LiRA with MBs**

- Integrating MBs into a LiRA → various combinations of standalone and self-bearing options are possible
- Tilting control of the mover necessary → MBs always at each axial end of a LiRA





- Distance between the segments  $\Delta z$  = linear stroke  $\rightarrow$  due to different PM arrangements in the mover MB + R  $\rightarrow$  conventional; MB + L  $\rightarrow$  interesting for further investigation!












## **Linear Actuator with Integrated MBs**

Topology Derivation
— Bearing Force Generation
Inverter Supply Requirements








### **Tubular Linear Actuator Derivation**

- Derivation of TLA  $\rightarrow$  tangential force for generating T in RA, generates drive  $F_d$  force in TLA
- TLA has fewer stray field compared to FLA due to the closed structure



- TLA has circumferential symmetry → it can not generate bearing (radial) force, i.e., no MBs are possible
- **FLA** can generate bearing force  $F_{\rm h}$ , but there is an attraction force between the mover PMs and the stator iron


[ref] Mirić. Spasoje, Johann W. Kolar, and Dominik Bortis, "Novel tubular linear actuator with integrated magnetic bearing," e & i Elektrotechnik und Informationstechnik 139.2 (2022): 230-242.







## **Tubular Linear Actuator (TLA)**

- Three-phase ring windings → maximum usage of copper, no end winding
- d axis aligned with the peak flux density wave of the mover;  $\theta$  is the electrical angle in a linear direction



$$\gamma_{\rm A} = 0, \, \gamma_{\rm B} = -2\pi/3, \, \gamma_{\rm C} = 2\pi/3$$





$$i_{A}^{d} = \hat{I}_{d} \cos(\theta + \theta_{i}^{d} + \gamma_{A})$$

$$i_{B}^{d} = \hat{I}_{d} \cos(\theta + \theta_{i}^{d} + \gamma_{B})$$

$$i_{B}^{d} = \hat{I}_{d} \cos(\theta + \theta_{i}^{d} + \gamma_{B})$$

$$i_{C}^{d} = \hat{I}_{d} \cos(\theta + \theta_{i}^{d} + \gamma_{C})$$


- TLA can generate linear drive force  $F_d$ ; bearing force  $F_b$  is not possible to achieve with the TLA dq coordinated in a linear direction  $\Rightarrow$  stationary coordinates representation of the three-phase winding





## xy Winding for Bearing Force Generation/Control

- A coil of the TLA split into 4 pieces,  $x \text{and } y \text{direction} \rightarrow \text{bearing force } F_h \text{ generation possible}$
- Bearing force generation capability  $\rightarrow$  depends on the linear position of the mover/PM poles



- $\blacksquare d$  current component in a linear direction needed
- $F_{\rm h}$  generation possible if PM is facing the stator teeth  $\rightarrow$  as long as there is non-zero flux linkage
- Mover/PM linear position changes in during the operation of the actuator


**ETH** zürich






## xy Winding and Three-Phase ABC Linear Winding

- Bearing force currents  $\rightarrow$  'd component' in a linear direction, must not generate drive (linear) force
- $\blacksquare$  xy current components (circumferential)  $\rightarrow$  determined by the desired force direction



$$i_{\rm xd}^* = i_{\rm x}^* = \frac{F_{\rm x}^*}{K_{\rm b}}$$
  $i_{\rm xq}^* = 0$ 

$$i_{yd}^* = i_y^* = \frac{F_y^*}{K_b}$$
  $i_{yq}^* = 0$ ,



$$i_{\text{x}\{A,B,C\}}^* = i_{\text{xd}}^* \cdot \cos(\theta + \theta_i^b + \gamma_{\{A,B,C\}})$$

$$i_{y\{A,B,C\}}^* = i_{yd}^* \cdot \cos(\theta + \theta_i^b + \gamma_{\{A,B,C\}})$$

- $\bullet$   $i_{xd}^*$  and  $i_{vd}^*$  calculated from the force components that should act on the mover (e.g., obtained by position controller)
- heta is the electrical angle determined by the mover's axial position  $z o heta = \pi \cdot z/ au_{
  m p}$

[ref] Mirić, Spasoje, Dominik Bortis, and Johann Walter Kolar. "Design and comparison of permanent magnet self-bearing linear-rotary actuators." 2019 12th International Symposium on Linear Drives





## xydq Transformation

- 4 stationary components  $\rightarrow xy$  for bearing force (rotary dir.) & dq for drive force (linear dir.)
- Variable x can be votage v, current i or flux linkage  $\psi$

$$\begin{array}{c|c} \text{Linear Direction} \\ \hline \text{Rotary Direction} \\ \hline \begin{bmatrix} x_{\text{xd}} & x_{\text{xq}} \\ x_{\text{yd}} & x_{\text{yq}} \end{bmatrix} = \begin{bmatrix} x_{\text{xA}}^{\text{b}} & x_{\text{xB}}^{\text{b}} & x_{\text{xC}}^{\text{b}} \\ x_{\text{yA}}^{\text{b}} & x_{\text{yB}}^{\text{b}} & x_{\text{yC}}^{\text{b}} \end{bmatrix} \times \frac{2}{3} \begin{bmatrix} \cos(\theta + \gamma_{\text{A}}) & -\sin(\theta + \gamma_{\text{A}}) \\ \cos(\theta + \gamma_{\text{B}}) & -\sin(\theta + \gamma_{\text{B}}) \\ \cos(\theta + \gamma_{\text{C}}) & -\sin(\theta + \gamma_{\text{C}}) \end{bmatrix}$$


- 12 phase windings, but 6 phase quantities  $\rightarrow$  windings on the same axis connected in series
- Linear direction → ABC three-phase quantities; dg stationary coordinates quantities






## abc Winding for Bearing and ABC Winding for Linear Motion

- Bearing force control with a three-phase winding  $abc \rightarrow xy$  current components determine the  $\hat{I}_h$  and  $\phi$
- $\varphi$  electrical angle for rotary direction;  $\theta$  electrical angle for linear direction





$$i_{\rm xd}^* = i_{\rm x}^* = \frac{F_{\rm x}^*}{K_{\rm b}} \qquad i_{\rm xq}^* = 0$$

$$i_{\rm a\{A,B,C\}}^* = \hat{I}_{\rm b}\cos(\varphi + \gamma_{\rm a})\cdot\cos(\theta + \theta_{\rm i}^{\rm b} + \gamma_{\rm \{A,B,C\}})$$

$$i_{\rm b\{A,B,C\}}^* = \hat{I}_{\rm b}\cos(\varphi + \gamma_{\rm b})\cdot\cos(\theta + \theta_{\rm i}^{\rm b} + \gamma_{\rm \{A,B,C\}})$$

$$i_{\rm b\{A,B,C\}}^* = \hat{I}_{\rm b}\cos(\varphi + \gamma_{\rm b})\cdot\cos(\theta + \theta_{\rm i}^{\rm b} + \gamma_{\rm \{A,B,C\}})$$

$$i_{\rm b\{A,B,C\}}^* = \hat{I}_{\rm b}\cos(\varphi + \gamma_{\rm c})\cdot\cos(\theta + \theta_{\rm i}^{\rm b} + \gamma_{\rm \{A,B,C\}})$$

$$i_{\rm c\{A,B,C\}}^* = \hat{I}_{\rm b}\cos(\varphi + \gamma_{\rm c})\cdot\cos(\theta + \theta_{\rm i}^{\rm b} + \gamma_{\rm \{A,B,C\}})$$

$$\begin{split} i_{\mathrm{a\{A,B,C\}}}^{\mathrm{b}} &= \hat{I}_{\mathrm{b}} \cos(\varphi + \gamma_{\mathrm{a}}) \cdot \cos(\theta + \theta_{\mathrm{i}}^{\mathrm{b}} + \gamma_{\{\mathrm{A,B,C}\}}) \\ i_{\mathrm{b\{A,B,C\}}}^{\mathrm{b}} &= \hat{I}_{\mathrm{b}} \cos(\varphi + \gamma_{\mathrm{b}}) \cdot \cos(\theta + \theta_{\mathrm{i}}^{\mathrm{b}} + \gamma_{\{\mathrm{A,B,C}\}}) \\ i_{\mathrm{c\{A,B,C\}}}^{\mathrm{b}} &= \hat{I}_{\mathrm{b}} \cos(\varphi + \gamma_{\mathrm{c}}) \cdot \cos(\theta + \theta_{\mathrm{i}}^{\mathrm{b}} + \gamma_{\{\mathrm{A,B,C}\}}) \\ \gamma_{\mathrm{A}} &= 0, \ \gamma_{\mathrm{B}} = -2\pi/3, \ \gamma_{\mathrm{C}} = 2\pi/3 \end{split}$$


- Comparison between xy and abc winding type  $\rightarrow$  capability for the bearing  $F_b$  and the drive  $F_d$  force generation
- Rotary direction  $\rightarrow abc$  three-phase quantities; xy stationary coordinates quantities





## abcdq Transformation

- 4 stationary components  $\rightarrow xy$  for bearing force (rotary dir.) & dq for drive force (linear dir.)
- Variable x can be votage v, current i or flux linkage  $\psi$



abcdq Transformation

- abcABC winding, three-phase rotary and three-phase linear  $\rightarrow$  9 phase quantities
- Bearing current component & Drive current component  $\rightarrow combined$  or separated windings









## xyABC Winding Inverter Supply

- Bearing force and driving force function  $\rightarrow$  realized with the *combined* or *separated* windings
- Combined winding  $\rightarrow$  each phase winding contains the *bearing* and the *drive* current components
- **■** Combined winding, 12 half-bridges

for Industry Applications (LDIA). IEEE, 2019.

#### ■ Separated winding, 9 half-bridges





- Combined winding  $\rightarrow$  each winding needs a dedicated half-bridge; star points with the linear three-phase system Separated winding  $\rightarrow$  anti-series connection of the bearing windings, no induced back EMF











**ETH** zürich

## abcABC Winding Inverter Supply

- Bearing force and driving force function  $\rightarrow$  realized with the *combined* or *separated* windings
- Combined winding  $\rightarrow$  each phase winding contains the *bearing* and the *drive* current components
- **■** Combined winding, 9 half-bridges



#### ■ Separated winding, 12 half-bridges



- Combined winding → each winding needs a dedicated half-bridge; star points with the linear three-phase system
- Comparison in terms of the bearing and the drive force generation capability → combined versus separated windings









## **Comparison of the Winding Types**

- Magnetically Levitated Tubular Actuator (MALTA)
- 2 modules necessary to control the tilting of the mover



					_
Winding	Shown	Force/ $F_{d,TLA}$		Number of	_
Realization		Drive	Bearing	Half-bridges	→ for 2 m
Combined					-
$3 \times 3$ -phase	Fig. 4.10(a)	0.78	1.12	18	
2 × 3-phase	Fig. 4.10(b)	0.76	1.1	24	
Separated					
$3 \times 3$ -phase +3-phase	Fig. 4.10(c)	0.57	0.81	24	
$2 \times 3$ -phase +3-phase	Fig. 4.10(d)	0.29	0.46	18	



**TLA Winding:** benchmark for comparison

- Comparison with respect to the driving force of the conventional TLA; 15 W of copper losses; fixed volume abcABC winding or  $3 \times 3$  phase MALTA  $\rightarrow$  the largest forces; the lowest number of the inverter half-bridges

[ref] Spasoje Miric, 'Linear-Rotary Bearingless Actuators,', PhD Thesis, ETH Zurich, 2021.









## MALTA Prototype Design

Magnetic Design 18-phase Inverter Supply Verification Measurements














## **Stator Design**

- Choice of the tooth width  $\tau_t$  and the tooth depth  $r_t \to \text{considering drive, bearing, pull forces}$ Scenario for the pull force calculation  $\to$  the mover sitting on the touch-down bearing (start-up of the MBs)







- The drive and the bearing forces  $\rightarrow$  obtained for the maximally possible continuous copper losses Geometry parameters  $\tau_t$  and  $r_t$   $\rightarrow$  chosen such that the pull force is lower than the bearing force


[ref] Mirić, Spasoje, et al. "Design and experimental analysis of a new magnetically levitated tubular linear actuator." IEEE Transactions on Industrial Electronics 66.6 (2018): 4816-4825.






## **Mover Design**

- Two mover types considered → surface-mounted PMs (SPM) and interior PMs (IPM)
- First step → parameter range calculated using scaling laws





#### ■ PM geometry range from the scaling law:

$$\frac{D_{\text{pm}} + 2r_{\text{ag}}}{D - 2r_{\text{bi}}} = [0.5, 0.7] \qquad D_{\text{pm}} = (D - 2r_{\text{bi}}) \cdot [0.5, 0.7] - 2r_{\text{ag}}$$
$$= [24 \text{ mm}, 35.2 \text{ mm}]$$

■ Final geometry parameters obtained by 3D-FEM:

$$au_{
m pp}=30~{
m mm}$$
  $au_{
m pm}=10~{
m mm}$   $au_{
m pm}=27~{
m mm}$   $au_{
m pm}=3~{
m mm}$ 

- Compromize between performance parameters → drive / bearing forces and axial (linear) acceleration
- The chosen IPM design → axially magnetized PMs and iron rings allow for simplified manufacturing


[ref] Spasoje Miric, 'Linear-Rotary Bearingless Actuators,', PhD Thesis, ETH Zurich, 2021.






## **Eddy Current Losses**

- Short stroke linear actuator → average/max. speed of the mover low to induce eddy current losses
- Solid iron used for the core design → final design check for the eddy current losses



**Maximum expected operation conditions:** 20g acceleration 30 mm stroke



- Average eddy current losses during the operation  $= 0.7 \text{ W} \rightarrow 4.7\%$  of the allowed copper losses Long stroke actuators that achieve higher speeds  $\rightarrow$  should use low loss core, e.g., soft magnetic composite (SMC)

[ref] Mirić, Spasoje, Dominik Bortis, and Johann Walter Kolar. "Design and comparison of permanent magnet self-bearing linear-rotary actuators." 2019 12th International Symposium on Linear Drives

[ref] Jensen, William R., Thang Q. Pham, and Shanelle N. Foster. "Linear permanent magnet synchronous machine for high acceleration applications." 2017 IEEE International Electric Machines and








## **MALTA Hardware Prototype**

- Mover's conductive sleeve → mechanical protection & eddy current position sensing
- Test bench with positioning stages and force sensors → machine constant measurements











## **MALTA Inverter Supply**

#### Specifications

24 phases ( $8 \times 3$  phase)

DC link voltage: 45 V


DC link capacitance:  $4 \times 22$  mF (buffer braking energy)


Power Semi.:  $80 \text{ V}, 10 \text{ A}, 15 \text{ m}\Omega$ 

 $2 \times position sensor interfaces$ 

Control Board: ZYNQ, Z-7020 (156 digital IOs)

#### **Current measurement:**













### **MALTA Hardware Prototype Measurements**

Measurements: flux linkage, force constants, thermal resistance → prototype characterization/model verification





#### **▼** Magnetic

$$\widehat{\Psi}_{M} = 8.5 \text{ mWb}$$

$$K_{\rm D} = 7.6 \, {\rm N/A}$$

$$K_{\rm R}=5.9~{\rm N/A}$$

#### **▼** Thermal

$$R_{\rm th} = 1.51 \, {\rm K/W}$$

$$\tau_{th} \approx 30 \ min$$

- Flux linkage measurement  $\rightarrow$  measure induced back EMF and integrate to get the flux linkage Force constant measurement  $\rightarrow$  apply known current and read the force sensor  $R_{\rm th}$  measurement (winding hot spot to ambient)  $\rightarrow$  apply known losses and read the built-in NTC temp. sensors









## universität innsbruck

## **Bearing Force Constant, Decoupling of Bearing and Drive Forces**

Dependence on the rotary angle → measured and simulated with 3D-FEM (saved in a lookup table for control implem.)







Decoupling of the bearing and the drive force generation!









## Attraction/Pull Constant $K_A$ (Pull Force)

- Extremely important parameter for the control system design and implementation
- $K_{\rm A}$  (also  $K_{
  m pull}$ ) determines poles of the mechanical dynamic model of the mover





 $K_{\Delta}$  obtained by displacing the mover in radial direction and measuring pull force, with no currents in the winding



universität innsbruck








### **Position Sensor**

Operating Principle Driving Electronics Geometry Optimization









## **Position Sensing – Linear & Radial**

- Sensing locations at the axial ends of the actuator → SP1 and SP2
- Linear position  $\rightarrow$  Hall-effect-based sensors, displaced  $\pi/2$  electrical



$$h_{\cos} = (h_1 + h_2 + h_3 + h_4)/4$$


$$h_{\rm sin} = (h_1 + h_2 + h_3 + h_4)/4$$



$$\theta_{\rm el} = {\rm atan2}(h_{\rm sin}, h_{\rm cos})$$

#### **Axial/Linear Position:**

$$z = \frac{L_{\rm p}}{\pi} (\theta_{\rm el} + k \cdot 2\pi)$$



- Radial position sensor → eddy-current based; conductive mover surface is a sensing target
- Advanced eddy-current sensing techniques → later in the tutorial, blood pump part











## **Eddy-Current Based Position Sensor**

- Injection coil carries high-frequency current → induce voltage in pick-up coils
- Upper limit for the oscillation frequency → resonant frequency of the sensor (layout/size dependent)



universität innsbruck



Mutual Inductances:

 $M_{\text{ini-x1}} = M_0$ 

 $M_{\text{inj-x2}} = M_0$ 

 $M_{\text{ini-v1}} = M_0$ 

 $M_{\text{ini-v2}} = M_0$ 

$$L_{x1}$$
 $L_{x1}$ 
 $L_{x2}$ 
 $L_{x1}$ 
 $L_{x2}$ 
 $L_{x1}$ 
 $L_{x2}$ 
 $L_{x2}$ 
 $L_{x1}$ 
 $L_{x2}$ 
 $L_{x1}$ 
 $L_{x2}$ 
 $L_{x1}$ 
 $L_{x2}$ 
 $L_{x2}$ 
 $L_{x2}$ 
 $L_{x1}$ 
 $L_{x2}$ 
 $L_{x2}$ 
 $L_{x1}$ 
 $L_{x2}$ 
 $L_{x3}$ 
 $L_{x2}$ 
 $L_{x3}$ 
 $L_{x2}$ 
 $L_{x3}$ 
 $L$ 

$$M_{\rm inj-x1} = M_0 + \frac{\partial M_{\rm inj-x1}}{\partial x} \Delta x$$

$$M_{\rm inj-x2} = M_0 + \frac{\partial M_{\rm inj-x2}}{\partial x} \Delta x$$

$$M_{\rm inj-y1} = M_0 + \frac{\partial M_{\rm inj-y1}}{\partial y} \Delta y$$

 $i_{\rm inj} = \hat{I}_{\rm inj} \sin(\omega_{\rm osc} t)$ 

 $\omega_{\rm osc} \approx 3$  MHz,  $\hat{l}_{\rm inj} \approx 100$  mA

$$M_{\rm inj-y2} = M_0 + \frac{\partial M_{\rm inj-y2}}{\partial y} \Delta y$$


- Anti-series connection of pick-up coils of the same axis  $\rightarrow$   $(L_{x1} \leftrightarrow L_{x2})$  and  $(L_{v1} \leftrightarrow L_{v2})$
- At center position ind. voltage of anti-series connection is zero; it is non-zero if there is mover displacement





## **Eddy-Current Sensor Electronics**

- x axis example  $\rightarrow$  the induced voltage  $\Delta e_x$  rectified and low-pass filtered results in  $U_x$
- The same electrical circuit is employed for the y axis



$$U_{\rm x} \sim 2\omega_{\rm osc} \, \hat{I}_{\rm inj} \, \frac{\partial M}{\partial r} \, \Delta x$$

 $\omega_{\rm osc} \approx$  3 MHz,  $\hat{I}_{\rm inj} \approx 100$  mA

- **Eddy-current position sensor processing electronics**
- $\partial M/\partial r$  inductance sensitivity with radial displacement  $\rightarrow$  maximized by the sensor geometry optimization
- Oscillation frequency  $\omega_{
  m osc}$  limited by the resonance; injection current  $i_{
  m inj}$  limited by the oscillator power











## **Eddy-Current Sensor Geometry Optimization**

- Optimization parameters  $\rightarrow$  angle between the pick-up coils  $\alpha$  and the number of turns N of the pick-up coils
- Maximize sensitivity about the radial displacements of the mover  $\rightarrow \partial M/\partial r$







- Optimum number of turns  $N \rightarrow$  larger N does means larger size of the pick-up coil
- Reasonable angle  $\alpha \rightarrow$  leave space for the signal processing electronics (analog circuits & ADCs)










### **Dynamic Modeling**

Dynamic Model Derivation Model Analysis Relative Gain Array











### **Controller Structure**

- Linear motion, radial position and tilting of the mover should be controlled
- Interaction (force action) points between the stator and the mover  $\rightarrow$  middle of the stator (module)





- **■** Controller structure
- Cascaded controller structure → outer position controller (slow) and inner current control loop (fast)

  Dynamic modelling of the plant → electrical model, mechanical model, position sensor model

[ref] Mirić, Spasoje, et al. "Dynamic electromechanical model and position controller design of a new high-precision self-bearing linear actuator." IEEE Transactions on Industrial Electronics 68.1 (2020):









### **Dynamic Models for Controller Design**

- Dynamic models necessary for the controller design → electric, mechanical, position sensor model
- Electric model  $\rightarrow abcdq$  transformation of the phase quantities; dq currents control forces on the mover





Overview of the dynamic models

- Mechanical model → MIMO model, coupling between the axes of motion; equations of motion must be derived
- Position sensor model → mech. model obtains COG coordinates, position sensor measures displacements











## Inertial $\mathcal I$ and Rotary $\mathcal R$ Reference Frames

- Inertial reference frame  $\rightarrow$  between modules, point O; rotary reference frame  $\rightarrow$  mover's COG, point  $O_{COG}$
- Position of the rotary RF with respect to inertial RF determines the mover's position





■ Inertial reference frame

**■** Rotary reference frame

- $l_{\rm B}$  the distance between the force action point and  $\mathcal{O}$ ;  $l_{\rm S}$  the distance of the position sensors Electrical angles  $\Rightarrow \theta$  linear electrical angle;  $\varphi$  rotary electrical angle (bearing force direction)


[ref] Mirić, Spasoje, et al. "Dynamic electromechanical model and position controller design of a new high-precision self-bearing linear actuator." IEEE Transactions on Industrial Electronics 68.1 (2020): 744-755.





## **Equations of Motion (EoM)**

- Newton-Euler equations of motion  $\rightarrow$  equation of motion in IRF (1) and rotation equation in RRF (2)
- Interaction points  $_{1}P_{1}$  and  $_{2}P_{2} \rightarrow$  center of the stator (module)



$$\vec{q}_{\mathrm{t}} = \begin{bmatrix} x \\ y \\ z \end{bmatrix}$$
  $\vec{q}_{\mathrm{r}} = \begin{bmatrix} \alpha \\ \beta \\ \gamma \end{bmatrix}$ 

$$m\frac{\partial^2 \vec{q}_{\rm t}}{\partial t^2} = {}_{\mathcal{I}}\vec{F}_{\rm tot} \quad (1)$$

$$m\frac{\partial^{2}\vec{q}_{t}}{\partial t^{2}} = {}_{I}\vec{F}_{tot}$$
(1)
$$\mathcal{R}\mathbf{I}_{m} \cdot \frac{\partial_{\mathcal{R}}\vec{\omega}}{\partial t} + \mathcal{R}\vec{\omega} \times \mathcal{R}\mathbf{I}_{m} \cdot \mathcal{R}\vec{\omega} = \mathcal{R}\vec{T}_{tot},$$
(2)

m - mass of the mover  $_{\mathcal{D}}I_{m}$  - MoI of the mover

IRF - inertial reference frame RRF - rotary reference frame

$$_{\mathcal{R}}\mathbf{I}_{\mathbf{m}} = \begin{bmatrix} I_{xx} & 0 & 0\\ 0 & I_{yy} & 0\\ 0 & 0 & I_{zz} \end{bmatrix}$$

- Cardan (Euler) angles  $\alpha, \beta, \gamma \rightarrow$  mover's rotation around respective axes  $x_{\mathcal{I}}, y_{\mathcal{I}}, z_{\mathcal{I}}$ In total 6 equations  $\rightarrow$  3 for linear motion and 3 for rotation

[ref] Mirić, Spasoje, et al. "Dynamic electromechanical model and position controller design of a new high-precision self-bearing linear actuator." IEEE Transactions on Industrial Electronics 68.1 (2020):





### **Solution of the EoM and Linearization**

- Solution of the EoM is a nonlinear function  $\rightarrow$  linearized to get the standard form of EoM
- Standard form of EoM  $\rightarrow$  characterize the mass and the stiffness distributions within the system

$$\vec{F}_{\text{EoM}}\left(\frac{\partial^{2}\vec{q}}{\partial t^{2}},\frac{\partial\vec{q}}{\partial t},\vec{q},\vec{v}\right) = \begin{bmatrix} -\frac{m}{R}\frac{\partial^{2}\vec{q}_{\text{t}}}{\partial t^{2}} - \frac{\vec{I}}{F_{\text{tot}}} - -\frac{\vec{I}}{F_{\text{tot}}} \\ -\frac{\vec{I}}{R}\frac{\vec{J}}{F_{\text{tot}}} - \frac{\vec{J}}{R}\frac{\vec{J}}{F_{\text{tot}}} - \frac{\vec{$$

Nonlinear solution of the EoM

$$\mathbf{M} \frac{\partial^2 \vec{q}}{\partial t^2} + \mathbf{G} \frac{\partial \vec{q}}{\partial t} = \mathbf{S} \vec{q} + \mathbf{V} \vec{v},$$

■ Linearized solution of the EoM

States: 
$$\vec{q} = \begin{bmatrix} x \\ y \\ z \\ \alpha \\ \beta \\ y \end{bmatrix}$$
 Inputs:  $\vec{v} = \begin{bmatrix} f_{xB} \\ f_{yB} \\ f_{xB} \\ f_{yB} \end{bmatrix}$ 

$$\mathbf{M}_{6\times 6} = \mathbf{J} \left( \vec{F}_{\text{EoM}}, \frac{\partial^{2} \vec{q}}{\partial t^{2}} \right) \Big|_{\text{at ss}} \qquad \mathbf{G}_{6\times 6} = \mathbf{J} \left( \vec{F}_{\text{EoM}}, \frac{\partial \vec{q}}{\partial t} \right) \Big|_{\text{at ss}}$$

$$\mathbf{S}_{6\times 6} = -\mathbf{J} \left( \vec{F}_{\text{EoM}} \vec{q} \right) \Big|_{\text{at ss}} \qquad \mathbf{V}_{6\times 5} = -\mathbf{J} \left( \vec{F}_{\text{EoM}}, \vec{v} \right) \Big|_{\text{at ss}}$$

■ Linearization

- EoM matrices → M mass matrix; G gyroscopic matrix; S stiffness matrix;
- Second-order differential equations (DE)  $\rightarrow$  reduction the first order DE, i.e., the state space







## **EoM to State-Space Equations**

- Transform second order EoM to the first order state-space → double the number of states
- **Controller design standardized for state-space equations**

$$\frac{\vec{q}}{\partial t} \Rightarrow \text{Positions}$$
 
$$\frac{\partial \vec{q}}{\partial t} \Rightarrow \text{Speeds}$$

$$\vec{\xi} = \begin{bmatrix} \vec{q} \\ \partial \vec{q} \\ \partial t \end{bmatrix}_{[12 \times 1]}$$

$$\mathbf{A} = \mathbf{E}^{-1} \begin{bmatrix} \mathbf{0} & \mathbf{I} \\ \mathbf{S} & \mathbf{0} \end{bmatrix} \qquad \mathbf{B} = \mathbf{E}^{-1} \begin{bmatrix} \mathbf{0} \\ \mathbf{V} \end{bmatrix} \qquad \mathbf{C} = \begin{bmatrix} \mathbf{P} & \mathbf{0} \end{bmatrix},$$

$$\mathbf{B} = \mathbf{E}^{-1} \begin{bmatrix} \mathbf{0} \\ \mathbf{V} \end{bmatrix}$$

$$\mathbf{C} = \begin{bmatrix} \mathbf{P} & \mathbf{0} \end{bmatrix},$$

Extension of the states

$$\frac{\partial \vec{\xi}}{\partial t} = \mathbf{A}\vec{\xi} + \mathbf{B}\vec{v},$$
$$\vec{p} = \mathbf{C}\vec{\xi},$$

$$\frac{\partial \vec{\xi}}{\partial t} = \mathbf{A}\vec{\xi} + \mathbf{B}\vec{v},$$

$$\vec{p} = \mathbf{C}\vec{\xi},$$

$$\mathbf{P}(z) = \begin{bmatrix} 1 & 0 & 0 & 0 & -(l_{S}+z) & 0 \\ 0 & 1 & 0 & (l_{S}+z) & 0 & 0 \\ 1 & 0 & 0 & 0 & (l_{S}-z) & 0 \\ 0 & 1 & 0 & -(l_{S}-z) & 0 & 0 \\ 0 & 0 & 1 & 0 & 0 & 0 \end{bmatrix}$$

$$\vec{p} = \begin{bmatrix} x_{1} \\ y_{1} \\ x_{2} \\ y_{2} \\ z \end{bmatrix}$$

$$\vec{p} = \mathbf{P}(z) \begin{bmatrix} \vec{q}_{t} \\ \vec{q}_{r} \end{bmatrix}$$

Sensor measurements 
$$\frac{\cos x}{\cos x} = \begin{bmatrix} x_1 \\ y_1 \\ x_2 \\ y_2 \\ z \end{bmatrix}$$
  $\vec{p} = \mathbf{P} \ (z) \begin{bmatrix} \vec{q}_t \\ \vec{q}_r \end{bmatrix}$ 

- Position sensor model  $\rightarrow$  relates sensor measurements with COG coordinates (states) of the mechanical model
- Different quantities in the model (positions, angles, forces) → normalization

**ETH** zürich







### **Normalization**

■ Normalized state-space equations

- Normalization is important for the implementation & debugging → values get to the similar level, [-1,1]
- Absolute values before normalization → different nature (electrical, mechanical) and value range


$$\vec{\xi}_{\mathrm{pu}} = \mathbf{D}_{\xi}^{-1} \vec{\xi} \in \mathbb{R}^{10}, \qquad \vec{v}_{\mathrm{pu}} = \mathbf{D}_{v}^{-1} \vec{v} \in \mathbb{R}^{5}, \qquad \vec{p}_{\mathrm{pu}} = \mathbf{D}_{p}^{-1} \vec{p} \in \mathbb{R}^{5},$$

**■ MIMO** normalization

$$\frac{\partial \vec{\xi}_{pu}}{\partial t} = \mathbf{A}_{pu} \vec{\xi}_{pu} + \mathbf{B}_{pu} \vec{v}_{pu}, 
\vec{p}_{pu} = \mathbf{C}_{pu} \vec{\xi}_{pu}$$

$$\mathbf{D}_{\xi} = \begin{bmatrix} \mathbf{D}_{q} & \mathbf{0} \\ \mathbf{0} & \mathbf{D}_{\dot{q}} \end{bmatrix}, 
\mathbf{D}_{q} = \operatorname{diag}(x_{\max} & y_{\max} & z_{\max} & \alpha_{\max} & \beta_{\max}), 
\mathbf{D}_{\dot{q}} = \operatorname{diag}(\dot{x}_{\max} & \dot{y}_{\max} & \dot{z}_{\max} & \dot{\alpha}_{\max} & \dot{\beta}_{\max}), 
\mathbf{D}_{v} = \operatorname{diag}(f_{\operatorname{Bmax}} & f_{\operatorname{Bmax}} & f_{\operatorname{Bmax}} & f_{\operatorname{Bmax}} & 2f_{\operatorname{Dmax}}), 
\mathbf{D}_{p} = \operatorname{diag}(x_{\max} & y_{\max} & x_{\max} & y_{\max} & z_{\max}).$$

■ Normalization matrices diagonal



**■** Choice of normalization values

 $\dot{x}_{\text{max}} = \sqrt{\frac{4f_{\text{Bmax}} x_{\text{max}}}{m}}$ 

- Choice of the normalization (base) values → based on physical limits of the actuator
- Normalized state-space equations used for the system analysis and the controller design

[ref] Mirić, Spasoje, et al. "Dynamic electromechanical model and position controller design of a new high-precision self-bearing linear actuator." IEEE Transactions on Industrial Electronics 68.1 (2020): 744-755.



## Position Control Bandwidth, SISO or MIMO Controller

- Eigenvalues of the matrix A → determine the dynamics of the systems and the minimum required bandwidth
- Closed-loop position controller bandwidth → should be at least twice the maximum unstable pole


Symbol	Mode	Eigenvalue
$\lambda_{1,2}$	x	$\pm 218.92\mathrm{rad}\mathrm{s}^{-1}$
$\lambda_{3,4}$	y	$\pm 218.92\mathrm{rad}\mathrm{s}^{-1}$
$\lambda_{5,6}$	z	$\pm 0.9893  \mathrm{rad}  \mathrm{s}^{-1}$
$\lambda_{7,8}$	$\alpha$	$\pm 157.53  \mathrm{rad}  \mathrm{s}^{-1}$
$\lambda_{9,10}$	eta	$\pm 157.53  \mathrm{rad}  \mathrm{s}^{-1}$

■ Eigenvalues of the matrix A

$$\omega_{\rm c} = 2 \times \max \left( |\lambda_{\{1,2,3,4,5,6,7,8,9,10\}}| \right)$$
  
=  $2 \times 218.92 \, \text{rad s}^{-1}$   
=  $436 \, \text{rad s}^{-1}$ .

 Minimum closed-loop bandwidth of the position controller





RGA number

- RGA number → helps to identify the level of coupling between the input and outputs of the system
- Low RGA number → low coupling and SISO control possible


ref] Mirić, Spasoje, et al. "Dynamic electromechanical model and position controller design of a new high-precision self-bearing linear actuator." IEEE Transactions on Industrial Electronics 68.1 (2020 144-755.





## Simple Bandwidth Requirement Assessment

- Closed-loop bandwidth requirement → can be imposed by the disturbances
- Disturbance parameters of the LiRA with MBs  $\rightarrow m$  mass;  $K_{\text{pull}}$  attraction/pull constant



$$a_{\mathbf{X}} = \frac{2}{m} F_{\mathbf{X}}, \quad a_{\mathbf{y}} = \frac{2}{m} F_{\mathbf{y}}$$

$$G_{\text{OL}}(s) = \frac{\{x(s), y(s)\}}{F_{\{x,y\}}(s)} = \frac{2}{m s^2}$$





$$F_{\mathrm{pull,x}} = x \; K_{\mathrm{pull}}, \quad F_{\mathrm{pull,y}} = y \; K_{\mathrm{pull}}$$
  $K_{\mathrm{pull}} = 8330 \, \mathrm{N/m}$   $m = 0.360 \, \mathrm{kg}$   $m = 0.360 \, \mathrm{kg}$ 

$$G_{\rm D}^{\rm pu}(s) = \frac{x(s)/\hat{x}}{F_{\rm x}(s)/\hat{F}_{\rm x}} = \frac{2 K_{\rm pull}}{m s^2}$$

$$\omega_{\rm D} = \sqrt{\frac{2K_{\rm pull}}{m}} \qquad \qquad \omega_{\rm BW} > \sqrt{\frac{2K_{\rm pull}}{m}} \approx 220\,{\rm rad/s}$$

- Bandwidth imposed by disturbance
- Position controller  $\omega_{BW}=2\omega_{D}\approx 440~rad/s$   $\Rightarrow$  current controller bandwidth  $>5\cdot 440=2200~rad/s$  Current controller bandwidth  $\Rightarrow$  determines the stiffness capability of the MBs

**ETH** zürich








### **Controller Design**

MIMO and SISO Controllers

— Measurement Results
Tilting Control Example










### **MIMO Controller**

- Cascaded Control Structure
- **Outer Loop: Position Control (BW: 60 Hz)**
- Inner Loop: Current Control (BW: 470 Hz)




**Position Controller Tuning: LQG** 


744-755.

(MALTA – Magnetically Levitated Tubular Actuator)

### ■ Position Controller Structure ( $\vec{\xi}_{aug,pu} \in \mathbb{R}^{15}$ )



### ■ Current Controller Structure ( $I_{dq} \in \mathbb{R}^{4 \times 4}$ )











## SISO Controller (1)

- **Separated winding example**
- xy bearing winding



- Linear & bearing controller separated Bearing windings in anti-series conn.











## SISO Controller (2)

- Combined winding example
- abcABC winding



- Superimpose control signals
- 3 three-phase systems in linear dir.













### **MIMO – Measurement Results**

Axial Reference Tracking



#### Radial Position and Force



Time (ms)

Max. Radial Position Oscillation (1.5%):  $\pm 15~\mu m$ 

Mechanical Air Gap  $\pm 1000 \mu m$ 


Y-direction Compensates Gravity Force: 3.25 N






### **MIMO – Measurement Results**

- **Steady-State Positioning**
- Sensor Resolution  $\sim 1 \mu m$
- Number of Measured Samples: 2000





# Mean $mean(x_1) = 0.0335 \mu m$ $mean(y_1) = -0.0212 \mu m$

STD 
$$std(x_1) = 0.3883 \mu m$$
  $std(x_1) = 0.5579 \mu m$ 


#### Mean

mean
$$(x_2) = 0.0579 \mu m$$
  
mean $(y_2) = -0.0735 \mu m$ 


STD 
$$std(x_2) = 0.4827 \mu m$$
  $std(x_2) = 0.4956 \mu m$ 

#### Mover Tilting Control

- High Precision Applications (e.g. Pick-And-Place)
- Thermal Expansions of Parallel Kinematics



Tilting Experimental Verification:













### **SISO – Measurement Results**

#### Oscillatory Operation



- **Axial Sub-plant Bode Plot**
- **Blue: Analytically Derived Transfer Function**
- Red: Experimentally Verified Points:  $f_z =$ {1, 3, 5, ..., 19, 21} Hz



Demonstration of the Real Life Operation →







## **Linear Bearingless Actuator**

Video (10 Hz, 1 Hz)













### Generalized Complex Space Vector Modelling










## **Generic Complex Space Vector Modeling (1)**

■ Three-Phase (a, b, c) → Two-Phase (d, q)



#### **■ Example: Current Space Vector**

#### **▼** Three-phase currents

$$i_{a} = \hat{\mathbf{I}}_{\mathbf{R}} \cdot \cos(\omega_{\mathbf{R}}t + \boldsymbol{\varphi}_{i})$$

$$i_{b} = \hat{\mathbf{I}}_{\mathbf{R}} \cdot \cos(\omega_{\mathbf{R}}t + \boldsymbol{\varphi}_{i} - 2\pi/3)$$

$$i_{c} = \hat{\mathbf{I}}_{\mathbf{R}} \cdot \cos(\omega_{\mathbf{R}}t + \boldsymbol{\varphi}_{i} + 2\pi/3)$$

$$\underline{i} = \hat{\mathbf{I}}_{\mathbf{R}} \cdot e^{i \cdot \boldsymbol{\varphi}_{i}} \cdot e^{i \cdot \omega_{\mathbf{R}}t}$$


#### **▼** Space vector

$$\underline{i} = \hat{\mathbf{l}}_{\mathbf{R}} \cdot e^{i \cdot \boldsymbol{\varphi}_{\hat{\mathbf{l}}}} \cdot e^{i \cdot \omega_{\mathbf{R}} t}$$

$$\underline{i}_{\mathrm{dq}} = \hat{I}_{\mathbf{R}} \cdot e^{i \cdot \varphi_{\hat{i}}} = i_{\mathrm{d}} + i \cdot i_{\mathrm{q}}$$


#### **■** Rotary Machine: Torque

#### **▼** Stator: 6 concentrated coils



$$\underline{\psi}_{\mathrm{dq}} = \widehat{\Psi}_{\mathrm{R}}$$


#### **▼** PM Rotor: $N_{pp,R} = 4$



$$T_{\rm z} = \frac{3}{2} N_{\rm pp,R} \cdot \widehat{\Psi}_{\rm R} \cdot i_{\rm q}$$


#### **Linear Machine: Thrust Force**

#### **▼** Stator: 3 concentrated coils



$$\frac{\psi_{\mathrm{dq}} = \widehat{\Psi}_{\mathrm{L}}}{\omega_{\mathrm{L}} = \frac{2\pi}{\tau_{\mathrm{DD}}} \cdot v_{\mathrm{z}}}$$

#### **▼ PM Rotor: 4 poles**




$$F_{z} = \frac{3\pi}{\tau_{\rm pp}} \cdot \widehat{\Psi}_{L} \cdot i_{\rm q}$$




## **Generic Complex Space Vector Modeling (2)**

■ Rotary Machine: Bearing Force


**▼** Torque Generation




**▼** Bearing Force Generation



- Rotor in Center → No Flux Linkage
- Model: two coils in anti-series connection



- Displaced Rotor  $\Rightarrow \frac{d\hat{\Psi}_R}{dx} = \frac{d\hat{\Psi}_R}{dy} = \chi_{pm,R}$
- Flux linkage radial sensitivity



#### **▼** Three Phase Flux Linkage

$$\begin{aligned} \psi_{\mathrm{a}} &= \chi_{\mathrm{pm,R}} \cdot \left[ x \cdot \cos(\omega_{\mathrm{R}} t + \varphi_{\psi}) - y \cdot \sin(\omega_{\mathrm{R}} t + \varphi_{\psi}) \right] \\ \psi_{\mathrm{b}} &= \chi_{\mathrm{pm,R}} \cdot \left[ x \cdot \cos(\omega_{\mathrm{R}} t + \varphi_{\psi} - 2\pi/3) - y \cdot \sin(\omega_{\mathrm{R}} t + \varphi_{\psi} - 2\pi/3) \right] \\ \psi_{\mathrm{c}} &= \chi_{\mathrm{pm,R}} \cdot \left[ x \cdot \cos(\omega_{\mathrm{R}} t + \varphi_{\psi} + 2\pi/3) - y \cdot \sin(\omega_{\mathrm{R}} t + \varphi_{\psi} + 2\pi/3) \right] \end{aligned}$$

#### **▼** Space Vector

$$\underline{\psi} = \chi_{\text{pm,R}} \cdot (x + i \cdot y) \cdot e^{i \cdot \varphi_{\psi}} \cdot e^{i \cdot \omega_{R} t}$$

$$\underline{\psi}_{\mathrm{dq}} = \chi_{\mathrm{pm,R}} \cdot (x + i \cdot y) \cdot e^{i \cdot \varphi_{\psi}}$$

$$F_{\rm x} = \frac{3}{2} \cdot \chi_{\rm pm,R} \cdot i_{\rm d}$$
  $F_{\rm y} = \frac{3}{2} \cdot \chi_{\rm pm,R} \cdot i_{\rm q}$ 







## **Generic Complex Space Vector Modeling (3)**

#### **■ Linear-Rotary Machine**

**▼** Stator: 18 concentrated coils



**▼** PM Rotor:  $N_{pp,R} = 4$ 



#### **▼** Phase quantity

$$x_{\mathrm{aA}} = \hat{X}_{\mathrm{RL}} \cdot \cos(\omega_{\mathrm{R}} t + \varphi_{x}) \cdot \cos(\omega_{\mathrm{L}} t + \theta_{x}) \qquad \qquad \hat{X}_{\mathrm{RL}} \in \{\hat{U}_{\mathrm{RL}}, \hat{I}_{\mathrm{RL}}, \hat{\Psi}_{\mathrm{RL}}\}$$

$$\hat{X}_{RL} \in \{\hat{U}_{RL}, \hat{I}_{RL}, \hat{\Psi}_{RL}\}$$

#### **▼** Double space vector transformation

$$\underline{\underline{x}} \triangleq \frac{4}{9} \begin{bmatrix} 1 & \underline{a} & \underline{a}^2 \end{bmatrix} \begin{bmatrix} x_{aA} & x_{aB} & x_{aC} \\ x_{bA} & x_{bB} & x_{bC} \\ x_{cA} & x_{cB} & x_{cC} \end{bmatrix} \begin{bmatrix} 1 \\ \underline{b} \\ \underline{b}^2 \end{bmatrix}$$

$$\underline{\underline{x}} \in \{\underline{\underline{u}}, \underline{\underline{i}}, \underline{\underline{\psi}}\}$$

$$a = e^{i(2\pi/3)}$$

$$b = e^{\mathbf{j}(2\pi/3)}$$

▲ Rotary *i* complex plane

▲ Linear *i* complex plane


#### Double Complex Space Vector

$$\underline{\underline{x}} = \hat{X}_{RL} \cdot e^{i \cdot \varphi_X} \cdot e^{j \cdot \theta_X} \cdot e^{i \cdot \omega_R t} \cdot e^{i \cdot \omega_L t}$$

$$\underline{\underline{x}}_{\mathrm{dq}} = \hat{X}_{\mathrm{RL}} \cdot e^{i \cdot \varphi_{X}} \cdot e^{j \cdot \theta_{X}} = x_{\mathrm{dd}} + i \cdot x_{\mathrm{qd}} + j \cdot x_{\mathrm{dq}} + i \cdot j \cdot x_{\mathrm{qq}}$$



$$\underline{\psi}_{\mathrm{dq}} = \psi_{\mathrm{dd}} = \widehat{\Psi}_{\mathrm{RL}}$$



Source: Jin et al., 2012

#### **■ Torque and Linear Force**

$$T_{z} = \frac{9}{4} N_{pp,R} \cdot \widehat{\Psi}_{RL} \cdot i_{qd}$$

$$F_{\rm z} = \frac{9\pi}{2\tau_{\rm pp}} \cdot \widehat{\Psi}_{\rm RL} \cdot i_{\rm dq}$$

#### **Bearing Force**

Rotary phase rescheduling needed

$$F_{\rm x} = \frac{9}{4} \cdot \chi_{\rm pm,RL} \cdot i_{\rm dd}$$

$$F_{y} = \frac{9}{4} \cdot \chi_{\text{pm,RL}} \cdot i_{\text{qd}}$$






## **Generic Complex Space Vector Modeling (4)**


- Linear Force Generation
- Simpler than full linear-rotary machine

#### **▼** Stator: 9 concentrated coils



$$\psi_{\mathrm{dq}} = \widehat{\Psi}_{\mathrm{M}}$$

#### **▼ PM Mover**



$$F_{z} = \frac{9\pi}{\tau_{\rm pp}} \cdot \hat{\Psi}_{\rm M} \cdot i_{\rm q}$$

- **■** Bearing Force Generation
- Linear-rotary machine with  $\omega_{\rm R}=0$

#### **▼** Flux linkage

$$\underline{\underline{\psi}} = \chi_{\text{pm,M}} \cdot (x + i \cdot y) \cdot e^{i \cdot \varphi_{\psi}} \cdot e^{j \cdot \theta_{\psi}} \cdot e^{j \cdot \omega_{L}}$$

$$\chi_{\text{pm,M}} = \frac{d\widehat{\Psi}_{\text{M}}}{dx} = \frac{d\widehat{\Psi}_{\text{M}}}{dy}$$

$$\underline{\psi}_{\mathrm{dq}} = \chi_{\mathrm{pm,M}} \cdot (x + i \cdot y) \cdot e^{i \cdot \varphi_{\psi}} \cdot e^{j \cdot \theta_{\psi}}$$

$$F_{x} = \frac{9}{4} \cdot \chi_{\text{pm,M}} \cdot i_{\text{dd}}$$

$$F_{y} = \frac{9}{4} \cdot \chi_{pm,M} \cdot i_{qd}$$








### **Double Stator LiRA**

Stator Arrangement Cooling of Inner Stator Geometry Optimization






universität innsbruck



## **Double Stator (DS) LiRA Realization Options**


- Stator Arrangement
- Outer → Linear, Inner → Rotary




• With and


Mover Types

• With and Without Back Iron



• Outer → Rotary, Inner → Linear










## **Cooling of the Inner Stator**

- Heat Flow Conduction Paths
- Outer Stator: Radial Heat Flow
- Inner Stator: Axial Heat Flow



- Winding Temperature:  $T_{c12} > T_{c1}$
- Unequal Temperature Distribution due to Axial Heat Flow and Thermal Resistance

Reduction of Axial Thermal Conductivity


Rotary Stators Inner Stator

Mover

Mechanical Support

Heat Flow

- Iron Core Thermal Conductivity: ~20 W/(mK)
- Copper Pipe Thermal Conductivity:  $\sim 400 \text{ W}/(\text{mK})$



Optimization Between 'Magnetic' and 'Thermal' Material









## **Analytic Thermal Model**

- Inner Linear Stator
- Hot Spot Temperature:  $T_{c12} < 120^{\circ}$ C



#### Outer Rotary Stators


• Hot Spot Temperature:  $T_{\rm w1-6} < 120^{\circ}$ C



#### **■ Thermal Model Equivalent Circuit**

 $\frac{L_{\text{tooth}}}{L_{\text{w1}}}$ 

 $\downarrow$   $|_{\bullet}w_{\text{tooth}}$ 









#### **DS LiRA Geometry Optimization**

- Parametrize Geometry
- Outer Dimensions Fixed: L = 100 mm, D = 100 mm
- Air Gaps:  $r_{ag} = 0.7 \text{ mm}$
- Copper Pipe Hole:  $D_{hole} = 8 \text{ mm}$  (Sensor Cables)
- Max. Winding Temp.: 120°C



- Models:
  - -Magnetic: 2D-FEM
  - -Thermal: Analytic Lumped Parameter Circuit Network >

- Automatized Optimization Procedure
- Discrete Design Space











# 74/175 \_

#### **Optimization Results**


- **Torque vs. Linear Force Pareto Plots**
- **Compromise Between Torque/Force and Acceleration**





**Chosen Design:**  $5.3 \text{ krad/}s^2$ 123.5  $m/s^2$ 6.24 Nm 181.5 N

- 3D FEM Flux Density Distribution in the Chosen Design
- Flux Density Evaluated for Double the Continues Current
- Outer stator: < 2.1 T, Inner Stator: < 1.4 T, Mover: < 2.1 T




Hardware Prototype →



## **DS LiRA Prototype**

- 3D CAD Model
- 'Exploded View' of the Outer Rotary and Inner Linear Stator



- Inner Stator: 12 × Coil Windings,
  - $1 \times \text{Lin. Pos. Sensor PCB}$ ,
  - 1 × Power Connection PCB
- Outer Stator: 12 × Concentrated Windings,
  - 2 × Rotary/Radial Pos. Sensor PCBs,
  - 1 × Power Connection PCB

- Prototype Realization
- Outer Rotary Stator





DS LiRA



Mover










#### **18-Phase Inverter Supply**


#### ■ Schematic

• LC Output Filter with Parallel RC Damping



- Power Semiconductors: 600 V, 70 mΩ, CoolGaN MOSFET
- Inductor:  $L = 80\mu\text{H}$ , N87, RM12, 23 Turns, 71 $\mu$ m Strand
- Capacitance:  $C = 4.8 \mu F$  for  $THD_{vout} = 1\%$
- Heatsink Design:  $CSPI = 12 \text{ W}/(\text{K}dm^3)$

#### **■** Hardware Realization











#### **Current & Position Controller**

- **Current Control Structure**
- Input:  $i_{out}$  References  $\rightarrow$  From the Position Controller



- 'Decentralized' Position Control
- Dedicated PID Controller for Each Motion Mode









#### **DS LiRA Measurement Results**

#### Rotary Step



#### Rotary Step: Radial Positions



#### **References:**

$$x_1^* = 0$$
 $y_1^* = 0$ 
 $x_2^* = 0$ 
 $y_2^* = 0$ 

Deviations: ±50 μm









#### **DS LiRA Measurement Results**

Video









#### **Part 1 Summary**

- Linear Bearingless Actuator
- Integration of Magnetic Bearings into a Linear Actuator
- Radial Position and Tilting Control in Micro Meter Range
- High-Precision/Purity/Dynamic Linear Motor Applications
- **Linear-Rotary Bearingless Actuator**
- Coupling of Rotation, Linear Motion, Magnetic Bearings
- Automatized Semi-Numerical Optimization Procedure
- High-Precision/Purity Applications














# Part 2











#### **Outline**

#### Part 1

- **▶** Introduction
- LiRA Examples / Applications
- ► Linear Actuator with Integrated MBs
- **▶** Position Sensors
- Dynamic Modeling, Controller Design
- Generalized Complex Space Vector
- Double Stator LiRA
- Outlook

#### Part 2

- **►** Introduction
- ► Application: Blood Pumps
- Sensors for SB-LiRAs
- ► Design Example: the ShuttlePump
- Outlook

#### Part 3

- **►** Introduction
- WPT to Linear Actuators
- Orthogonal and Parallel Field Concept
- Supplying Multiple Receivers Voltage & Current Impressed WPT
- Outlook









#### **Blood Pumps**

Motivation
— Types and Applications ———
Existing Systems








#### **Heart Failure**

- > 26 million people worldwide, expected to increase with aging of population
- Congenital heart defects: ≈ 1% of newborns → complications



Source: ehnheart.com





Source: ox.ac.uk


- Heart transplantation: not enough donors → ≈ 20% of patients dies on the waiting list Urgent need for short- and long-term solutions → Mechanical Circulatory Supports (MCSs)





## **Heart Failure – Mechanical Circulatory Support (MCS)**

- Short-term (acute) → e.g. <u>Extra-Corporeal Membrane Oxygenation</u> (ECMO) Long-term (chronic) → e.g. <u>Ventricular Assist Devices</u> (VADs) or <u>Total Artificial Hearts</u> (TAH)



**■** Either case: keep blood circulating → Mechanical Circulatory Support (MCS), i.e. a blood pump











Pulsatile / Continuous Flow | Axial Flow / Centrifugal | Extra-Corporeal / Implantable


■ Common requirements: gentle blood handling (low hemolysis) | small volume



universität innsbruck

# **Blood Pumps – Pulsatile vs Continuous Flow**

- Pulsatile / "1st gen" / Positive displacement → Physiological, pneumatically or electrically driven
- Example: BerlinHeart EXCOR® | VAD (L/R/Bi), Paracorporeal







■ Larger / heavier / valves needed / external driving units








# **Blood Pumps – Pulsatile vs Continuous Flow**

- Continuous / "2nd gen" / Rotary Blood Pumps (RBPs) → electrically driven | efficient | compact
- **Example: Abbott HeartMate II | LVAD, Implantable**



■ Can be realized with just one moving part / no need for valves → reliability, durability









# **Blood Pumps – Axial Flow vs Centrifugal Flow**

- Continuous Flow Rotary Blood Pumps: two options
  Centrifugal flow → can integrate non-contact bearing options





Source: Rogers et al, 2017








# **Blood Pumps – Axial Flow vs Centrifugal Flow**

- Centrifugal flow / "2nd gen" / Rotary Blood Pumps (RBPs)
- **Example: Medtronic HeartWare HVAD | LVAD, Implantable**



## **HeartWare** Medtronic

■ Hybrid passive magnetic + hydrodynamic bearing










# universität innsbruck

# **Blood Pumps – Magnetically Levitated**

- Centrifugal flow / "3nd gen" / Rotary Blood Pumps (RBPs) with Magnetic Bearings
- **Example: Abbott HeartMate 3 | LVAD, Implantable**



Most advanced LVAD → direction for future systems










# **Total Artificial Hearts (TAH)**

- Bi-ventricular failure → more compact wrt 2 x VADs
- Same pump types as for LVADs | Not as mature, research and development needed



Rotary pumps OregonHeart **BiVACOR** 

- + Physiological, pulsatile flow
- Valves can promote thrombus formation
- Flexible membranes and valves can be risk prone to device failure
- SynCardia has excorporal pneumatic driving unit (not fully implantable)

- + High durability: one moving part, no valves
- High shear stresses because of spinning rotor
- No or limited pulsatile flow










# **Total Artificial Hearts (TAH)**

- Other research directions: entirely-soft 3D-printed TAH (silicone) | Developed @ ETH Zurich Only lasts for ≈ 3000 beats (45 mins) → feasibility / more research needed



Zurich Heart Ein Projekt der

Hochschulmedizin Zürich



Universität Zürich<sup>UZH</sup>















#### **Extra-Corporeal Blood Pumps**

- Short-term treatment: extra-corporeal circulation | bridging strategy | e.g. COVID patients
- Example: Abbott CentriMag ECMO | Rotary / Continuous Flow / Centrifugal







Source: cardiovascular.abbott

Low device-related thrombosis¹



Low Hemolysis<sup>1</sup>













Sensor Systems for SB-LiRAs

Sensor Types —— Non-contact Sensors ——— Use in SB-LiRAs












# Sensors for SB-LiRAs, what to measure?


- High precision requirements → Feedback control → Need precise measurements
- Linear, Rotary, Radial position/displacement sensors














Source: keba.com

**■** Especially important / demanding to enable MBs!



universität innsbruck








# **Position/Displacement Sensors – Non-contact**

- MBs → Non-contact sensors / large bandwidth (up to 1 kHz) / high precision (sub-μm range)
- Different options / operating principles



Capacitive: grounded target | Optical: no objects between sensor and target → Mostly suited: Magnetic and Eddy Current




universität innsbruck





#### **Hall-Effect Sensors**

- Magnetic sensors, based on Hall effect | Hall element + conditioning circuit → DC output
- Conveniently packaged as a single IC | Multiple elements (axes) possible in the same package



Bandwidth: typically ≈ 10 kHz range | Resolution: can reach μm → sensor location is crucial!








#### **Hall-Effect Sensors**

- Typical use in Rotary Machines: 3 sensors, 120°el displaced, detect (electrical) rotor angle
- Can use analogously for Linear Machines | Alternative: 2 sensors, 90°el displaced ('sin' and 'cos')




Main drawbacks: depend on PMs magnetization (irregular, aging, external fields!) / thermal drift





# **Eddy Current Sensors (ECSs)**

- Coil with high-frequency AC voltage excitation + conductive target → eddy currents induced
- Secondary field influences  $Z_{c,in}$  (dep. on coupling factor!)  $\rightarrow$  can measure distance  $\delta$  (rule of thumb: range  $\approx$  radius)



- Coil realization: typically spiral, one layer → low parasitic capacitance, higher SRF, can excite in MHz range
- High level of integration: PCB-embedded coils, also flexible






#### **Eddy Current Sensors (ECSs)**

- AC excitation, extract position information from impedance → sensor interface / post-processing circuit
- **■** Extensive literature about ECS interfaces for high performance sensors. Examples:

#### $\Delta Z$ to $\Delta U$


**Example: Differential AC Wheatstone Bridge** 



 $U_{\mathrm{br.out}}$  is AM-demodulated

#### $\Delta Z$ to $\Delta f$

**Example: Difference Relaxation Oscillator** 



Source: Zoethout, 2002


- Sensor interface determines achievable sensitivity / resolution / bandwidth / (non-)linearity
- Integrated interface solutions are becoming available (e.g. LDC, Texas Instruments)





## **Eddy Current Sensor "Seeing Through Walls"**

- Point of strength of ECSs: can tolerate objects in the air gap → suited for harsh / dirty environments
- Special application: ECS measuring through a conductive enclosure → high purity / sealed applications




- Possible in a specific frequency range defined by shield and target properties
- Rule of thumb: make the enclosure thinner and/or of a less conductive material wrt the target






# **Eddy Current Sensor "Seeing Through Walls"**

- Realized hardware prototype: PCB coil + evaluation board / analysis and verification of thermal drift
- Measurement circuit with quad. demod.  $\rightarrow$  distinguish between distance  $\delta$  and temperature T variations






#### **Temperature-controlled setup**

















LiRA with HBs: ShuttlePump


Machine Design — Sensor System Built Prototype






# **ShuttlePump**

- Implantable TAH based on a LiRA → opening/closing of inlets/outlets @5 Hz → valveless! Pulsatile flow → physiological












Design of the LiRA Motor Drive System @ PES – under realization





# **ShuttlePump**

- Linear Actuator: push blood in circulation → motion profile with force requirement
- High power density (up to 10 W peak in 200 cm³)



- Important constraints: 1) blood temperature increase < 2°C → minimize losses</p>
  - 2) overall device weight < 900 g, minimize piston weight
  - 3) outer diameter < 70 mm






#### **ShuttlePump – Hydrodynamic Bearing**

Source: Khonsari et al., 2017

- Rotary Actuator: continuous 3 mNm axial torque → establish journal HB
- **■** CFD simulations from Medical University of Vienna / HB design




■ Blood gap thickness: trade off radial load / blood heat-up → Suggested blood gap: 140 μm





# **ShuttlePump – Motor Concept**

- Permanent Magnet Synchronous Machine (PMSM): high power density, PMs embedded in the piston
- Minimize drive unit's complexity, i.e. number of phases / half bridges



■ Requirements for LA and RA highly differ → "Independent" machine design of LA and RA, 3 + 3 ph.

→ maximum lateral surface for LA





## ShuttlePump – LA Design

Tubular Linear Actuator (TLA), simplest possible stator / mover designs (1 pole pair)

	Distributed Winding	Concentrated Winding		
Slotted	A C B a C b	A a B b C c		
Slotless	A c B a C b	A a B b C c		
•	Radial Magnetization: Surface PM	<b>—</b>		
٠	Axial Magnetization: Interior PM	<b>←</b>		
	Stator: if slotted → minimum air s	gan, higher flux density, less current	needed -> less losses	









## ShuttlePump – LA Design

- Parameterization + Optimization with Finite Element Methods (FEM) simulations
- For fixed output axial force (43 N), objectives: least losses | least weight










th\_PM Permanent Magnet thickness

th\_bi Mover back iron thickness





- Maximize copper cross-section, while guaranteeing that iron does not saturate
- Important: edge effects, reluctance shaping, pole shoes, iron extensions






## ShuttlePump – LA Design and Radial Pull

■ Stator: if slotted → minimum air gap, higher flux density, higher reluctance forces (radial pull!)






- Trade-off: radial pull force vs axial force, i.e. copper losses
- ★Selected design: least copper losses (≈ 8 W) for maximum allowed radial pull (≈ 20 N)





## **ShuttlePump – LA Hardware Prototype**

- Stator realization: stacked rings, VACOFLUX50 (high B<sub>sat</sub> = 2.3 T) + ring coils Mover realization: discrete N50 neodymium PMs on VACOFLUX50 back-iron rings








## **ShuttlePump – RA Design**

Spatial constraints: mover geometry → 4 poles, only magnets of the same polarity inlets/outlets location → split the stator into two independent ones




- Slotted design → air gap unchanged, axial reluctance profile kept, no edge effects for the LA Two steps optimization → 2D FEM for RA only, final 3D FEM together with LA (full LiRA)





### **ShuttlePump – Sensor Concept**

- Contactless linear and rotary sensor needed. Enclosure: non-conductive
- Lateral surface occupied by LiRA stators. Far-away target: high sensitivity needed




- Differential ECS system (from the cylinder bases) | Specially-shaped PCB-embedded pick-up coils
- Compact sensor interface: excitation + AM-demodulation in one chip, analog output





## **ShuttlePump – Sensor Concept**

- Contactless linear and rotary sensor needed. Needed resolution ≈ 0.1 mm and ≈ 1 deg
- From rotary sensor can also extract linear position information ('mag' and 'arg')




Differential ECS system further enhances sensitivity and linearity





### **ShuttlePump – System Overview**

- Inverter + Control PCB: hosts Zynq 7010 SoC / 2 inverter modules switching @1MHz with output filters First prototype: external drive → percutaneous cable connection



■ ShuttlePump Firmware: current control / position + speed control / reference generation / fault detection / serial monitoring





## **ShuttlePump – Hardware Realization**

- Inverter + Control PCB: hosts Zynq 7010 SoC / 2 inverter modules switching @1MHz with output filters First prototype: external drive → percutaneous cable connection










## **ShuttlePump – Experimental Verification**

Mechanical test bench: LiRA commissioning / machine constants and radial pull verification









## **ShuttlePump – Experimental Verification**

- Hydrodynamic test bench (Mock Circulatory Loop) @ Charite' Berlin Sealed tanks ≈ blood vessels' compliance | Pressure and flow-rate sensors





140 mmHg, up to 10 L/min



■ Tested with external LiRA → next: with realized LiRA prototype









--- Outlook ----








**ETH** zürich



#### **Part 2 Outlook**

- Overview on Blood Pumps: types, use, existing systems
- Overview on non-contact position sensors for SB-LiRAs: types, use in machines Example SB-LiRA with HB: ShuttlePump LiRA design, sensor system, realization







### **Outline**

#### Part 1

- **▶** Introduction
- LiRA Examples / Applications
- Linear Actuator with Integrated MBs
- **▶** Position Sensors
- **▶** Dynamic Modeling, Controller Design
- Generalized Complex Space Vector
- Double Stator LiRA
- Outlook

#### Part 2

- **▶** Introduction
- Application: Blood Pumps
- Sensors for SB-LiRAs
- **▶** Design Example: the ShuttlePump
- Outlook

### Part 3

- ► Introduction
- WPT to Linear Actuators
- Orthogonal and Parallel Field Concept
- Supplying Multiple Receivers Voltage & Current Impressed WPT
- **▶** Outlook










Introduction





#### **Motivation**

- Supply power to a linear actuator which is enclosed in stainless steel (SS) housings.
- Highest hygiene in pharmaceutical, and semiconductor processing industries.



SS-enclosed linear actuator with cable carriers.




- Supply cables and cable carriers → difficult to seal & thoroughly clean.
- WPT through SS allows the removal of cables and cable carriers.







#### Introduction

- B through the SS sheets  $\rightarrow$  induced eddy current losses.
- Different types of WPT through SS → cause different eddy currents leading to different losses.





**▲** Orthogonal-field Concept (OFC).



▲ Parallel-field Concept (PFC).


- In OFC, the magnetic material area  $A_{
  m ofc}$  can be large  $ightarrow p \propto A_{
  m ofc} 
  ightarrow$  High losses (e.g. 72% efficiency).
- $A_{ofc}$  is much smaller  $\rightarrow$  eddy current induced is lower  $\rightarrow$  high efficiency  $\rightarrow$  PFC is studied.






## **Supply WPT**

- Power supply for a single receiver → voltage impressed WPT
- Multiple receivers → voltage sharing or current impressed





▲ Single Receiver

**▲** Multiple Receivers

In the case of PFC → high coupling due to closed toroidal core










— Orthogonal Field Concept (OFC) ——





## **Field Orthogonal to the SS Enclosure**

- Analyzed WPT through SS: E-core primary and secondary
- Transmitter & receiver: represented with  $W_1$  and  $W_2$




- Core flux density  $\overrightarrow{B}$  penetrates through the SS sheets in the air gap
- Flux density integration  $\rightarrow$  back emf  $\hat{E} \rightarrow$  induced eddy currents in SS






## **SS Eddy Current Distribution**

- Analysis of the eddy current distribution: 3D-FEM
- Simulation parameters: primary 100 A turns, secondary 0 A turns, 1 kHz exc. freq.






Most of the current induced in the SS concentrated between the limbs





## **WPT Through SS Modeling**

- Most of the induced current between the limbs  $\rightarrow$  replace SS with a short circuit winding  $W_3$
- Windings  $W_1$ ,  $W_2$  and  $W_3$  → three-winding transformer



$$\begin{split} u_1 &= R_1 i_1 + L_1 \frac{\mathrm{d}i_1}{\mathrm{d}t} + M_{12} \frac{\mathrm{d}i_2}{\mathrm{d}t} + M_{31} \frac{\mathrm{d}i_3}{\mathrm{d}t} \\ u_2 &= R_2 i_2 + L_2 \frac{\mathrm{d}i_2}{\mathrm{d}t} + M_{12} \frac{\mathrm{d}i_1}{\mathrm{d}t} + M_{23} \frac{\mathrm{d}i_3}{\mathrm{d}t} \\ 0 &= R_3 i_3 + L_3 \frac{\mathrm{d}i_3}{\mathrm{d}t} + M_{23} \frac{\mathrm{d}i_2}{\mathrm{d}t} + M_{31} \frac{\mathrm{d}i_1}{\mathrm{d}t} \end{split}$$


- Impact of the SS in the air gap  $\rightarrow$  a third short-circuited winding coupled with the primary & secondary
- Equivalent circuit of the WPT through SS system  $\rightarrow$





## **WPT Through SS Equivalent Circuit (1)**

- Mutual inductance per turn ( $M_0$ ) is equal for  $W_1$ ,  $W_2$  and  $W_3$ , otherwise mag. sym. is violated
- Equal  $M_0$  assumption  $\rightarrow$  scale mutual inductances with number of turns  $N_1$ ,  $N_2$  and  $N_3$



Magnetization inductance M can be defined → equivalent circuit






## **WPT Through SS Equivalent Circuit (2)**

- Further rearranging of equations using magnetization inductance M
- The third equation has zero voltage → in the SS branch connected to '-' potential

$$u_1 = R_1 i_1 + (L_1 - M) \frac{di_1}{dt} + M \frac{d}{dt} (i_1 + \frac{i_2}{n} + \frac{i_3}{m})$$

$$nu_2 = n^2 R_2 \frac{i_2}{n} + (n^2 L_2 - M) \frac{d^{\frac{i_2}{n}}}{dt} + M \frac{d}{dt} (i_1 + \frac{i_2}{n} + \frac{i_3}{m})$$

$$0 = m^2 R_3 \frac{i_3}{m} + (m^2 L_3 - M) \frac{d^{\frac{i_3}{m}}}{dt} + M \frac{d}{dt} (i_1 + \frac{i_2}{n} + \frac{i_3}{m})$$



• Values of the parameters → from 3D-FEM eddy-current simulation








## **WPT Through SS Equivalent Circuit Parameters**

- WPT system geometry → determined such that 50 W can be transferred
- Primary/secondary core → two stacked E 47/20/16 N87 ferrite cores




• Parameters obtained from 3D-FEM simulation using  $\underline{Z}_{11}$ ,  $\underline{Z}_{12} = \underline{Z}_{21}$  and  $\underline{Z}_{22}$  complex impedances





## Model Verification with 3D-FEM: Coupling k Calculation

- $\blacksquare$  Coupling coefficient k calculated from the equivalent circuit
- Series equivalent of the magnetization branch:  $L_{12} = (M_0 R_3^2)/(R_3^2 + (2\pi f \cdot M_0)^2)$



$$k = \frac{L_{12}(f)}{L_{12}(f) + L_{s1}}$$

$$k = \frac{M_0}{\omega^2 \cdot L_{s1} \left(\frac{M_0}{R_3}\right)^2 + L_{s1} + M_0}$$

if 
$$R_3 \to \infty$$
 then:  $k = \frac{M_0}{L_{s1} + M_0}$ 


• Coupling k dependence on frequency  $\rightarrow$  second order low pass filter






## **Analytic Calculation of Circuit Parameters**

■ Based on the current distribution in the SS  $\rightarrow R_{SS}$  is calculated






• Inductances calculated based on the magnetic circuit model





## **WPT Through SS Resonant Compensation**

- Series resonant compensation  $\rightarrow$  self-inductance  $L_{11} = L_{s1} + L_{12}$  or stray inductance  $L_{s1}$
- Rather low SS resistance value  $\rightarrow$  self-inductances  $L_{11}/L_{22}$  are frequency dependent



$$L_{12} = \Im(j\omega M || R_{ss}) \frac{1}{\omega}$$

$$C_1 = \frac{1}{\omega^2 L_{\rm s1}}$$

$$C_2 = \frac{1}{\omega^2 L_{s2}}$$


- Stray inductances  $L_{s1}/L_{s2}$  are not frequency dependent
- Compensation of stray inductances leads to higher efficiency







## **Fundamental Frequency Modeling, Equivalent Load Resistance**

■ 'Notch'-pass characteristic of the input impedance



$$R_{\rm L,eq} = \frac{8}{\pi^2} \frac{U_{2,\rm DC}^2}{P_2}$$






- Pulsed input voltage → only fundamental component of the load current!
- Equivalent load resistance  $\rightarrow$  models delivered output power  $P_2$












**Prototype Design** 






### **Optimum Number of Turns**

- In this work primary & secondary number of turns assumed equal,  $N_1 = N_2$
- $\blacksquare$   $R_0, M_0, R_3 \rightarrow$  parameters per turn  $(N_1 = N_2 = 1)$  determined by the core geometry



Input Voltage	Output Voltage	Output Power
$\hat{U}_1 = 50  \mathrm{V}$	$\hat{U}_2 = 50  \mathrm{V}$	$P_2 = 50 \mathrm{W}$

$$R_{\rm L,nom} = \frac{\widehat{U}_2^2}{2P_2} = 25 \,\Omega$$



$$N_{1,\text{opt}} = \sqrt{\frac{R_{\text{L,nom}}}{\sqrt{R_0(R_0 + 2R_3)}}} \approx 180$$


• Optimum number of turns  $\Rightarrow R_{\rm L,nom} > R_{\rm w}$  and  $R_{\rm L,nom} < R_{\rm ss}$ 





## **Hardware Prototype**

- Primary & secondary cores → two stacked E 47/20/16 N87 ferrite cores
- Primary & secondary windings  $\rightarrow N_1 = N_2 = 180$ , 0.5 mm wire diameter



Parameter	3D FEM	Prototype	Rel. Error
$R_{ m w,dc}$ $L_{ m s}$ $M$ $R_{ m ss}$	$\begin{array}{c c} 1.8\Omega \\ 2.5\mathrm{mH} \\ 5.6\mathrm{mH} \\ 160\Omega \end{array}$	$1.9\Omega \ 2.62\mathrm{mH} \ 5.4\mathrm{mH} \ 155\Omega$	5.3% $4.6%$ $3.7%$ $3.2%$


• Model & prototype parameter values considered up to 10 kHz excitation frequency






### **AC Winding Resistance**

- Impedance measurements on the prototype → proximity effects in the windings
- Frequency dependent winding resistance  $R_{\rm w}(f)$  → included in the model using  $G_{\rm R}(f)$





$$R_{\rm w}(f) = R_{\rm w,dc}(1 + 2G_{\rm R}(f) \cdot H^2)$$

$$H^{2} = \frac{\frac{R_{\rm w}(10 \text{ kHz})}{R_{\rm w,dc}} - 1}{2G_{\rm R}(10 \text{ kHz})}$$

• Further details/references on  $G_{\rm R}(f)$  can be found the in the paper manuscript






 $f_{\min} = 1.6 \text{ kHz}$ 

 $f_{\text{max}} = 2.3 \text{ kHz}$ 

# Optimal Excitation Frequency $f_{opt}$

- lacktriangle Frequency dependent winding resistance  $R_{\mathrm{w}}(f)$   $\Rightarrow$  there is  $f_{\mathrm{opt}}$  s.t. efficiency is max.
- Frequency dependent winding resistance  $R_w(f)$  → there is  $R_L = R_{L,opt}(f)$  s.t. eff. is max.




$$R_{\text{L,opt}} = \frac{\sqrt{R_{\text{w}}}\sqrt{R_{\text{w}}^2 + 3R_{\text{w}}R_{12} + 2R_{12}^2 + 2(\omega L_{12})^2}}{\sqrt{R_{\text{w}} + R_{12}}}$$






- Res. comp. caps.  $\rightarrow C_1 = C_2 = 1.9 \, \mu F$
- Operation frequency → 2.25 kHz (71.2 % efficiency)












Power & Efficiency Measurements






## **Regulation of Power via Input Voltage**

■ Verification of the circuit model with the power & efficiency measurements



$$R_{\rm L} = 24 \, \Omega$$

$$\frac{P_{\rm ss}}{P_2} = \frac{R_{12}(R_{\rm L} + R_{\rm w})^2}{R_{\rm L}(R_{12}^2 + X_{12}^2)}$$




- Efficiency does not depend on the input voltage
- SS losses  $P_{ss}$  increase linearly with the output power  $P_2$  ( $R_L$  is constant!)






# Regulation of Power via Load Resistance $R_L$

■ Verification of the circuit model with the power & efficiency measurements



$$\widehat{U}_1 = [20, 40, 60] \text{ V}$$

$$\frac{P_{\rm ss}}{P_2} = \frac{R_{12}(R_{\rm L} + R_{\rm w})^2}{R_{\rm L}(R_{12}^2 + X_{12}^2)}$$



- Efficiency heavily depends on the load resistance R<sub>L</sub>
- Larger output power P<sub>2</sub>, while keeping the SS losses P<sub>ss</sub> limited










—— Coaxial WPT (PFC) ——






#### **OFC and PFC**

- B through the SS sheets  $\rightarrow$  induced eddy current losses.
- Different types of WPT through SS → cause different eddy currents leading to different losses.



**▲** Orthogonal-field Concept (OFC).



▲ Parallel-field Concept (PFC).

- In OFC, the magnetic material area  $A_{
  m ofc}$  can be large  $ightarrow p \propto A_{
  m ofc} 
  ightarrow$  High losses (e.g. 72% efficiency).
- $A_{ofc}$  is much smaller  $\rightarrow$  eddy current induced is lower  $\rightarrow$  high efficiency  $\rightarrow$  PFC is studied.










# Parallel-field Concept WPT









## Parallel-field Concept WPT — SS Loss Model

- Calculation of eddy-current losses  $\rightarrow P_{ss} \propto V_{ss}, F(\chi), \sigma_{ss}, \delta_{ss}, \omega_{ss}, F(\chi), \widehat{B}_{ss}$
- SS losses depend only on the primary current.



▲ Arrangement of the PFC WPT.



▲ Electrical equivalent circuit.


• The SS losses can be modeled in the same way as (primary-side) winding losses.







## Parallel-field Concept WPT — Primary Winding Design

- To find the best arrangement of the wires: 2D-FEM at  $N_1=12$ ,  $f_{\rm sw}=50~{\rm kHz}$ .
- lacktriangle Simulation parameters: Round  $ightarrow d_{\rm w}=1.85~{
  m mm}$  ; Flat  $ightarrow \delta_{\rm w}=0.9mm$  ,  $b_{\rm w}=1.2mm$ , and  $d_{\rm w}=17~{
  m mm}$ .







▲ 2D-FEM of analysis of different arrangement of wires.

Arr  $R_{\rm ac}/R_{
m dc}$  vs Frequency.

- **A** Normalized Winding resistance vs Windign thinkness  $\delta_{
  m w}$ .
- The lowest AC resistance  $\rightarrow$  the wires at the circumference, i.e., the flat wire should be used.
- Increasing  $\delta_w$  above the skin depth does not lead to a further reduction of the winding resistance anymore.


[ref] Mirić, Spasoje, et al. "Wireless Power Supply of Moving Linear Actuator Enclosed in Stainless-Steel." 2022 Wireless Power Week (WPW). IEEE, 2022.





## Parallel-field Concept WPT — SS Tube Thermal Model

■ The SS surface  $T_{SS}$  should be kept below 60°C.



Circulate the current through the pipes, and measure the power and the temperature increase.


- **▲** Primary-side thermal model.
- To keep  $T_{\rm ss} < 60^{o}$ C at  $T_{amb} = 40^{o}$ C, the losses in the primary should be  $P_{\rm ss} + P_{\rm cu1} < 13.3$  W.





## Parallel-field Concept WPT — Electric Equivalent Circuit

- $Arr R_{w1,w2}$  depends on the operating frequency and the winding geometry  $Arr R_{w1,w2} = R_{ac}(f_{sw})$ .
- $L_{s1}$  is the external stray inductance  $\rightarrow L_{s1} = \mu_0 \log[x_{s1}/(d_w/2)]L_{SS}N_1^2/\pi$ .
- $L_{s1c}$  is much smaller than  $L_{s1} \rightarrow L_{s1c} = L_{s1}(h/L_{ss})$ .
- $L_{\rm m}$  is calculated from the  $A_{\rm L}$  value of the core  $\rightarrow L_{\rm m} = A_{\rm L} N_1^2$ .
- $C_{r1}$  is resonant capacitor  $\rightarrow C_{r1} = 1/[\omega^2 \cdot (L_{s1} + L_{sc1})]$ .



 PFC WPT system with a single receiver: conceptual physical arrangement and electrical equivalent circuit.

Different from the OFC WPT, SS losses do not depend on the air gap field in PFC WPT.










# — Mode of Operation — —








## Parallel-field Concept WPT — Voltage-Impressed DCX Operation

- High magnetic coupling → operation of the WPT system as a series resonant converter.
- Switching frequency  $\leq$  resonant frequency  $\rightarrow$  soft switching achieved  $\rightarrow$  "DC transformer" (DCX).



- The DCX couples the output voltage tightly to the input voltage without the need for closed-loop control.
- There is no need for a communication link between the primary and the secondary side.









# -Hardware Prototype----








#### **Hardware Prototype — Optimization result**

- Swept parameters for different power levels: frequency  $f_s = 5 \cdots 60$  kHz, turns  $N_1 = N_2 = 4 \cdots 20$  turns.
- Number of secondary cores:  $N_{\text{stacked}} = 1$ .




- $\blacktriangle$  Efficiency vs output power in dependence of the operating frequency  $f_s$  and the number of turns in the primary  $N_1$ .
- Optimum operation frequency  $\rightarrow$  consequence of the core loss model:  $P_{\rm core} \propto B^a \cdot f^b$ .
- The blue line indicates the best design with one stacked core ( $N_{stacked} = 1$ ,  $N_1 = 16$  turns,  $f_s = 20$  kHz).






## **Hardware Prototype — Number of Cores on the Secondary**

- The magnetic material area  $A_{fe}$  is increased by increasing the number of stacked cores  $N_{stacked}$ .
- 1 core → 90 gram, 2 stacked cores → 180 gram.





$$\Psi_{\rm m} = \frac{U_{\rm in}}{4 \cdot f_{\rm s}} = \frac{72}{4 \cdot 20 \rm k} = 0.9 \rm mWb$$

$$\Phi_{\rm m} = \frac{\Psi_{\rm m}}{N_1} = B_{\rm m} \cdot A_{\rm fe} = B_{\rm m} \cdot N_{\rm stacked} \cdot A_{\rm core}$$

$$B_{\rm m} = \frac{\Psi_{\rm m}}{N_1 \cdot N_{\rm stacked} \cdot A_{\rm core}}$$


- ▲ Efficiency versus output power in dependence of the number of stacked cores.
- ▲ Equivalent circuit.
- Higher efficiency and/or power transfer can be achieved with two cores ( $N_{stacked} = 2$ ).
- Stacking the cores  $\rightarrow$  lower  $N_1 \rightarrow$  reduce the  $R_1$  accordingly  $\rightarrow$  larger efficiency and output power.






#### **Hardware Prototype — Measurement**

- Prototype of a linear x z actuator with a PFC WPT system  $\rightarrow V_{dc} = 72 \text{ V}$ ,  $f_s = 20 \text{ kHz}$ , and  $P_{out} = 300 \text{ W}$ .
- The inverters supplying the linear motors move together with the linear actuator's slider (in the x-direction).







▲ Measured key waveforms during a mechanical load step

- The efficiency is up to 97% through SS (Wireless power transfer efficiency).
- Good load regulation without the need for a closed-loop control system.







# **Hardware Prototype — Operation**












## — Multi-Receiver PFC WPT —









## **Multiple Receivers**— Automatic Time-Sharing Operation

- More than one receiver → magnetic series connection of the secondary windings → the output voltage is uncontrollable (shared by the number of secondaries).
- Automatic time-sharing operation for the PFC WPT linked to multiple receivers without communication and close-loop control.





▲ Conceptual physical arrangement of multiple receivers


▲ Electronical equivalent circuit of multiple receivers







## **PFC WPT — Operation with Multiple Receivers**

- $\blacksquare$  Multiple independent drivers and power suppliers  $\rightarrow$  coupling between the receivers.
- **■** Time-sharing approach for multiple receivers.







**▲** Two receivers WPT circuit.

▲ Simulation results.

• The relative on-times depend on the respective output powers as:  $D_{a \text{ or } b} = \frac{P_{a \text{ or } b}}{P_a + P_b}$ .









## **Hardware Prototype — Two receivers**

- Prototype of 2 linear x z actuators with a PFC WPT system  $\Rightarrow V_{dc} = 72 \text{ V}, f_s = 20 \text{ kHz}, \text{ and } P_{out} = 100 \text{ W} * 2.$
- Automatically adjusts switching duration of each module.



**▲** Hardware prototype



**▲** Experimental result at transition.

(One module has a load step change from full load to half load, while the other is at full load.)





# **Hardware Prototype — Two receivers**

#### ■ Video












— Current Impressed PFC ——






#### **Voltage-Impressed WPT vs. Current-Impressed WPT**

- Single receiver with voltage-impressed WPT (DC-X) → load-independent operation
- Multiple receivers → Equivalent to multiple loads connected in series
   Voltage-impressed WPT → Voltage is shared between loads → time sharing control
  - Current-impressed WPT → load-independent operation




**▲ Voltage-impressed WPT** 

**▲** Single-receiver



**▲ Voltage-impressed WPT** 


**▲** Multiple-receivers



**▲** Current-impressed WPT

**▲** Multiple-receivers

- Voltage-impressed system can be converted to a current-impressed system
- **■** Symmetric T-network:









#### **Current-Impressed WPT, Single Receiver**

■ Current-impressed WPT for a single receiver  $\rightarrow$  Active rectifier to keep constant  $U_{\rm out}$  for different  $R_{\rm L}$  ■ The impressed current  $i_1$  designed such that for the nominal load and  $d_{\rm r}=1$ ,  $U_{\rm out}=U_{\rm out,nom}$ 

(c)





(d)

$$i_{\text{out}} = \begin{cases} 0, & \text{MOSFETs are ON} \\ i_1, & \text{MOSFETs are OFF} \end{cases}$$

$$R_{\rm L,ci} = \frac{8}{\pi^2} \sin^2\left(\frac{\pi}{2} d_{\rm r}\right) R_{\rm L}$$


- The equivalent load resistance  $R_{\rm L,ci}$  → depends on the duty cycle  $d_{\rm r}$  The same current-impressed network can be used for any number of the receivers







#### **Current-Impressed WPT, Multiple Receivers**

■ The current-impressed (CI) WPT network for a single receiver can be used for multi-receiver CI WPT







$$\hat{U}_{f} = \sqrt{(R_1 + n \cdot R_{L,ci,N})^2 + X^2} \cdot \hat{I}_{1}$$

$$\approx \sqrt{(n \cdot R_{L,ci,N})^2 + X^2} \cdot \hat{I}_{1}$$


■ The voltage over  $C_f$  capacitor increases linearly with the number of receivers n






#### **Voltage- vs Current-Impressed WPT**

■ Voltage-impressed → eq. load resistors in parallel; Current-impressed → eq. load resistors in series





■ Voltage-impressed  $\rightarrow$  increased current  $i_1$  over primary coil; Current-impressed  $\rightarrow$  increased voltage over  $C_f$ 







# **Voltage- vs Current-Impressed WPT**

#### **■** Specifications of the System

Parameter	Name	Value
Voltage-In		
$Specification$ $U_{out}$		72 Vdc
	Desired output voltage	4 V
$\Delta U_{\rm out}$	Maximum voltage ripple	4 V 100 W
$P_{\text{out,a}}$	Nominal output power	50 W
P <sub>out,b</sub> Calculation	Nominal output power and Simulation Results	50 W
$R_{\mathrm{La}}$	Load resistance	$51.84\Omega$
$R_{ m Lb}$	Load resistance	$103.68\Omega$
$R_{ m La,vi}$	Equivalent load resistance	$42.02\Omega$
$R_{ m Lb,vi}$	Equivalent load resistance	84.04 Ω
$R_{ m L,vi}$	Equivalent load resistance	$28.03\Omega$
Ical	Input current RMS	2.19 A
$I_{1,\mathrm{rms}}^{\mathrm{cal}}$ $I_{1,\mathrm{rms}}^{\mathrm{sim}}$	-	2.14 A
I <sub>1,rms</sub>	Input current RMS	2.14 A
Current-In	npressed	
Specification	ns	
$U_{ m out}$	Desired output voltage	$72\mathrm{Vdc}$
$\Delta U_{\mathrm{out}}$	Maximum voltage ripple	4 V
$P_{ m out,a}$	Nominal output power	$100\mathrm{W}$
$P_{ m out,b}$	Nominal output power	$50\mathrm{W}$
	and Simulation Results	
$d_{\mathrm{ra}}$	Rectifier duty cycle	1
$d_{ m rb}$	Rectifier duty cycle	0.33
$R_{\mathrm{La}}$	Load resistance	$51.84\Omega$
$R_{ m Lb}$	Load resistance	$103.68\Omega$
$R_{ m La,ci}$	Equivalent load resistance	$42.02\Omega$
$R_{ m Lb,ci}$	Equivalent load resistance	$21.01\Omega$
$R_{ m L,ci}$	Equivalent load resistance	$63.03\Omega$
$I_1$	Impressed current RMS	1.53 A
$I_{ m in}$	Input current RMS	2.37 A
$\hat{U}_{\mathrm{f}}^{\mathrm{cal}}$	Simulated peak $C_f$ voltage (17)	167.8 V
$\hat{U}_{\mathrm{f}}^{\mathrm{sim}}$	Simulated peak $C_{\rm f}$ voltage	163.5 V


Parameter	Name	Value
Inverter		
$U_{ m dc}$	Input DC link voltage	$72\mathrm{V}$
$f_{ m s}$	Switching frequency	$20\mathrm{kHz}$
$d_{ m i}$	Inverter duty cycle	0.5
Compensa	tion	
$L_{ m f}$	T-network inductance	$334 \mu H$
$C_{ m f}$	T-network capacitance	$189\mathrm{nF}$
$L_{ m t}$	$X_{\rm t}$ inductance	$34 \mu H$
Transform	er	-
$R_1$	Primary resistance	$1.5\Omega$
$L_{ m s1}$	Primary stray inductance	$300  \mu H$
$L_{ m m}$	Magnetization inductance	$12\mathrm{mH}$
$N_1$	Number of primary turns	16
$N_2$	Number of secondary turns	16
Rectifier	•	
$U_{ m out}$	Desired output voltage	$72\mathrm{Vdc}$
$P_{ m out,N}$	Nominal output power	$100\mathrm{W}$
$d_{ m r,N}$	Nominal rectifier duty cycle	1





## **Voltage- vs Current-Impressed WPT**

■ Voltage-Impressed (left) and Current-Impressed (right)








#### **Part 3 Outlook**

- OFC and PFC wireless power transfer
  Multiple receivers → Voltage impressed & Current impressed











—— Biography ——







#### **Biography of the Speaker**



SPASOJE MIRIC (M') received B.Sc., M.Sc., and Ph.D. degrees in electrical engineering from the University of Belgrade, School of Electrical Engineering in 2012, 2013, and 2018 respectively, focusing on power electronics systems and drives. In 2021 he defended his second Ph.D. thesis at ETH Zurich at the Power Electronic Systems Laboratory (PES) in the advanced mechatronic systems area. More specifically, during his Ph.D. project, he focused on linear-rotary actuator systems with magnetic bearings, resulting in two new machine

topologies patented. Since 2021, he has been with PES as a post-doc researcher, focusing on WBG power converter optimization with hard and soft-switching, new modulation techniques of flying capacitor converters, wireless power transfer systems, and eddy-current-based position sensor systems. He was appointed Ass. Professor and Head of the Innsbruck Drives and Energy Systems Laboratory at the University of Innsbruck (UIBK) on Jan. 1, 2023. DDr. Miric proposed a novel self-bearing actuator topology and a generalized complex space vector calculus for linear-rotary machines. He has published 20+ scientific papers in international journals and conference proceedings and filled 7 patents. He has presented 2 educational seminars at leading international conferences and received 5 IEEE Transactions and Conference Prize Paper Awards.

From 1<sup>st</sup> of January 2023 → TT Ass. Prof. @ University of Innsbruck

**New Laboratory:** 

**Drive and Energy Systems Laboratory (i-DES)** 

www.uibk.ac.at/mechatronik/ides/














Thank you!





